





SX700-G V1.1



REF.ID.	PIN NO.	COLOR	V
PA	1	ORANGE	+3.3V
	2	ORANGE	+3.3V
	3	BLACK	COM
	4	RED	+5V
		RED	+5V
	5	BLACK	COM
	6	RED	+5V
	7	BLACK	COM
	8	GRAY	PWR_OK
	9	PURPLE	+5VSB
	10	YELLOW	+12V
	11	YELLOW	+12V
	12	ORANGE	+3.3V
		ORANGE	+3.3V
	13	BROWN	+3.3V (SENSE)
		BROWN	+3.3V (SENSE)
	14	BLUE	-12V
	15	BLACK	COM
	16	GREEN	PS_ON#
	17	BLACK	COM
	18	BLACK	COM
		BLACK	COM
	19	BLACK	COM
		BLACK	COM
20			
21	RED	+5V	
22	RED	+5V	
23	RED	+5V	
24	BLACK	COM	

REF.ID.	PIN NO.	COLOR	V	
PM	1	YELLOW	+12V	
	PM1	2	BLACK	COM
		3	BLACK	COM
		4	RED	+5V
PL	1	RED	+5V	
	PO	2	BLACK	COM
		3	BLACK	COM
		4	YELLOW	+12V
PE	1	ORANGE	+3.3V	
	PF	2	BLACK	COM
		3	RED	+5V
		4	BLACK	COM
		5	YELLOW	+12V
PB	1	BLACK	COM	
	2	BLACK	COM	
	3	BLACK	COM	
	4	BLACK	COM	
	5	YELLOW	+12V	
	6	YELLOW	+12V	
	7	YELLOW	+12V	
	8	YELLOW	+12V	
PC	1	YELLOW	+12V	
	2	YELLOW	+12V	
	3	YELLOW	+12V	
	4	BLACK	COM	
	5	BLACK	COM	
	6	BLACK	COM	
	7	BLACK	COM	
	8	BLACK	COM	

